


Programming instruction


Glydea ULTRA 35/60 RTS, Irisimo 45 WF RTS, Moveit® 35 RTS

1 Connect the RTS transmitter to the motor


Only connect one motor to power whilst programming



Press simultaneously until...



...motor jogs





Short press, UP or DOWN.

It's recommended to perform programming with curtain installed.


At the first command, open or close, the curtain will make a complete run, open & close, to record the hard end limits.


2 Check the motor rotation direction





OK → 4







NOT OK → 3

3 Change if needed motor rotation direction

2 sec.



Press until...



...motor jogs

4 Record a RTS transmitter




Press the prog button on the back of the control until...



...motor jogs


Glydea ULTRA 35/60 RTS, Iriso 45 WF RTS, MoveLite 35 RTS

Setting My position



Re-adjustment of end -limits

1 Place the curtain in the end limit you wish to adjust



2 Put the receiver in programming mode



3 Place the curtain in the new desired end limit



4 Repeat the process for the other end limit